



PROJECT FLOORS

the up-to-date company



Please read before ATTEMPTING INSTALLATION

Project Floors Vinyl Collections

Preparation:

- Subfloor must be permanently dry, smooth, level, clean and free from loose materials of any kind.
- Moisture content to be no more than 15 - 20%.
- **Acclimatize** flooring: Once onsite, remove tiles from their packaging and fan out like a deck of cards. Preferably for a minimum of 24 hours before laying, or as long as possible if time constraints exist.

Installation:

1. Work in **small areas at a time**.
2. Adhesive application: Use a **1mm "V" notched trowel** to spread the adhesive. As a guide 1 litre of adhesive should cover approx 4-5m².
3. While the adhesive is **still wet**, drop the tiles into place. Bed them in place using hand pressure.
4. Immediately wipe off any excess adhesive with a damp cloth.
5. Once the adhesive has had a chance to tack up, **roll the entire floor** with a 30-40kg floor roller. Repeat after 90 minutes.

Finish:

1. Vacuum, dust mop or damp mop to remove all loose dirt.
2. Apply polish (Platinum 25 / Satin) in a thin coat using a lint free mop and allow to dry thoroughly.
3. Subsequent coats should be applied at right angles to the previous one to ensure an even coverage.
4. Apply 2-3 coats total.

Maintenance:

- Clean floor using a neutral Ph cleaner